

**JT USA EXCELERATORS 5.0 & 6.0 PARTS LIST**

1	RECEIVER BODY	49	SEAR
2	VERTICAL FEED ADAPTER	50	PCBA SCREWS (4)
3	VALVE BODY	51	GRIP PANEL SCREWS (4)
4	VALVE BODY O-RINGS (2)	52	
5	BALL STOP	53	GRIP PANEL (LEFT)
6	BALL STOP COVER	54	GRIP PANEL (RIGHT)
7	BALL STOP COV. SCREWS (2)	55	
8	CA & DR. FORW. SCREWS (3)	56	SAFETY PIN SPRING
9	VALVE BODY PIN	57	SAFETY PIN STEEL BALL
10	VALVE BODY SCREW	58	SAFETY PIN
11	JT LOGO	59	SOLENOID SCREW (4) *
12	FIELD STRIP PIN	60	SEAR SPRING
13		61	REGULATOR BONNET
14	BARREL	62	EXP CHAMB. 90 DEG. ELBOW
15	BARREL O-RING	63	REGULATOR PISTON
16	BARREL PLUG	64	
17	BARREL PLUG O-RINGS (3)	65	REG. PISTON LARGE O-RING
18	BOLT	66	REG. PISTON SMALL O-RING (3)
19	BOLT O-RINGS (3)	67	REGULATOR SPRING
20	BOLT RELEASE PIN	68	REGULATOR ADJUSTER SLUG
21	BOLT RELEASE PIN BALL	69	REGULATOR MAIN BODY
22	BOLT RELEASE SPRING	70	VOL. EXP CH & CA O-RINGS (4)
23	BOLT RELEASE SET SCREW	71	REGULATOR O-RINGS (2)
24	STRIKER O-RING	72	REGULATOR OUTER SLEEVE
25	STRIKER	73	REGULATOR RETAINING RING
26	STRIKER SPRING	74	REGULATOR ADJUSTER SCREW
27	STRIKER BUMPER	75	DROP FORWARD
28	STRIKER SPRING GUIDE PIN	76	CA & DROP FORWARD WASHERS (3)
29	STRIKER PLUG	77	
30		78	BOTTOM LINE ADAPTER
31	VELOCITY ADJUSTER SCREW	79	BOTTOM LINE WASHERS (2)
32	VEL. ADJ. SCREW O-RING	80	BOTTOM LINE SCREWS (2)
33	VOLUMIZER	81	
34	WARNING LABEL	82	
35	CA ADAPTER	83	PRESSURE LINE ASSEMBLY
36	VALVE SPRING	84	
37	CUP SEAL GUIDE	85	
38	CUP SEAL	86	
39	VALVE PIN	87	SAFETY PIN O-RING
40	PRESSURE GAUGE	88	TRIGGER MICRO SWITCH
41	AIR FILTER SCREEN	89	PRINTED CIRCUIT BOARD/SMBY
42	TRIGGER FRAME	90	ELECT. CONTROL BUTTONS (3)
43	TRIGGER FRAME WASHERS (2)	91	
44	TRIGGER FRAME SCREWS (2)	92	TRIGGER SOLENOID
45	TRIG. MICR SWIT. SCREWS (2)	93	EXPANSION CHAMBER
46	TRIGGER PIN	94	ANTI-THEIF LABEL
47	TRIGGER	95	1/8" ALLEN WRENCH
48	SEAR PIN	96	3/32" ALLEN WRENCH

\* FACTORY SET. DO NOT ALTER!  
**BOLD-FACED PARTS: EXCELERATOR 6.0 UNIQUE PARTS**

